

## 1. Product Specification

<b>Model: ZDAC-236C</b>	Index
Operating Voltage	12VDC±10%; Current 1.2A
Lock Relay	12VDC/2A
Environmental temperature	working:0°C~45°C; storage:-10°C~55°C
Relative humidity	working:40%~90%RH;storage:-20%~90%RH
RFID Card Capacity	1000 cards
4-digits public PIN Capacity	1
Proximity Reader Frequency	125KHz
Compatible Cards	EM or EM compatible cards
Card Reading Distance	5—15CM

## 2. The LED and Buzzer

Status type	Green LED	Red LED	Buzzer
Normal Working State		flash	
Authorized Card Read /Valid PIN/Exit Button	on		a short beep
Wrong PIN Entered		flash	a long beep
Non Authorized Card Read		flash	a long beep
Acceptable Key Pressed		flash	a short beep
Door Sensor, Anti-Break Sensor Alarmed		flash	continuous beeps
Programming Mode	on	flash	2 short beeps
Key In Right Programming Instruction	on	flash	2 short beeps
Key In Wrong Programming Instruction	on	flash	3 short beeps

## 3. The Factory Default of the Product

Type	Factory Default
6-digit Programming PIN	990101
Door Open Mode	Authorized Card / Public PIN (Default Public PIN: 1234)
Lock Relay Time	3 seconds
Anti-Break Sensor Alarm	Disabled
Door Sensor Alarm	Disabled
Authorized Card Stored	none

## 4. Functions and Settings (All functions should be set in programming mode; the parameters can be set repeatedly; the effective setting should be the last one.)

- Enter programming mode:  
Press [\*]+[6 digits programming PIN], 2 beeps;  
Under programming state, it should be noted that:
  - The controller cannot perform normal function instructions.
  - If there is no programming instruction within 20 seconds, system will automatically quit programming mode and enter the normal working mode.
  - Successfully set parameters, 2 beeps;
  - Fail to set parameters, 3 beeps;
  - Before some setting instruction is finished (i.e. the controller have already given off 2 beeps for successful setting, or 3 beeps for failed setting), if the input instruction is mistaken, press [\*], the controller gives off a long beep, meaning that the setting of the instruction has been cancelled.
- Change programming PIN:  
Press [0]+[6 digits new programming PIN]+[repeat 6 digits new programming PIN], 2 beeps;
- Set door open mode:
  - Card or Public PIN:  
Press [1]+[0], 2 beeps;
  - Card plus Personal PIN:  
Press [1]+[1], 2 beeps;
- Set Lock Relay Time:  
Press [2]+[TT], 2 beeps; TT represents unlocking time, second as unit; if unlocking time is 3 seconds, TT=03;
- Set Public PIN:  
Press [3]+[4 digits public PIN], 2 beeps;  
Press [3]+[0000], 2 beeps, eliminate all “public PIN”

6. Set Anti-Break Alarm:
  - 1) Disable anti-break alarm: press [4]+[0], 2 beeps;
  - 2) Enable anti-break alarm: press [4]+[1], 2 beeps;
7. Enrolling Cards:
 

Press [5]+[8 digits card number] or [present a card to the controller], a beep, then 2 beeps, then the card was added successfully, if want to enroll the next card, press [the next 8 digits card number] or [present the next card to the controller], a beep, then 2 beeps, then the card was added successfully, enrolling more cards, repeat above mentioned operating steps, press [\*] to finish enroll cards in the end;

Notice:

  - 1)[8 digits card number]: there are two team card number on card commonly  
for example: 0016497924 251,48388

This control use “16497924”, if rearward 4 digits card number is same of two cards, the control enroll only one;

  - 2)After press [5]+[8 digits card number] or [present a card to the controller], the control give 3 beeps, meaning the card number is exist.
8. Set check door sensor state before open the door
  - 1) Disable check door sensor state: press [6]+[0], 2 beeps;
  - 2) Enable check door sensor state: press [6]+[1], 2 beeps
9. Deleting authorized card:
  - 1) Press [7]+[4 digits card number] or [present the card to the controller], 2 beeps.....[the next 4 digits card number] or [present the next card to the controller], press [\*] to finish deleting authorized cards in the end.
  - 2) Deleting all authorized cards: if the customer needs delete all cards, please restore the controller to factory defaults.
10. Set door sensor alarm state:
  - 1) Disable door sensor alarm function: press [8]+[0], 2 beeps;
  - 2) Enable door sensor alarm function: press [8]+[1], 2 beeps;
  - 3) After turning on this function, the controller will give off continuous long beep when the door is not closed after normal opening, or the door is not opened through the controller;
11. Restore factory defaults:
 

Press [8]+[6], 2 beeps, then 3 long beeps, 8 short beeps after 120 seconds, enter normal working state;
12. Enrolling A team connective Cards
 

Press [9]+[8 digits first card number]+[8 digits end card number], 2 beeps.
13. Exit programming state:
 

Press [\*], 2 beeps;

Under programming mode, if there is no programming instruction within 20 seconds, the system will automatically quit the programming mode and enter normal working mode.

## 5. Users' Instructions:

1. Card or public PIN mode:
  - 1) Read authorized card: After a short beep, green light is on, yellow light is off and the door is open.

2) Public PIN entered: Green light is on, yellow light is off and the door is open;

The customer should continuously type in 4 digits public PIN; the interval between each key pressing should be less than 2 seconds. If the interval is more than 2 seconds, the system will automatically quit this time's PIN input.

3) If the customer entered the wrong PIN, press [\*], and enter the right PIN again to open the lock.

### 2. Door opening mode of card + PIN

- 1) Read authorized card, after a beep,
  - (1) Enter the right 4 digits Public PIN within 5 seconds, the green light is on and the door is unlocked;
  - (2) Not enter the PIN within 5 seconds, the buzzer gives off a long beep and the door is not unlocked;
  - (3) Wrong 4 digits PIN is entered, the buzzer gives off a long beep and the door stays locked; read card again, enter the right PIN to unlock the door.
  - (4) Wrong PIN for less than 4 digits, press [\*], need not to read card again, directly input the right PIN and unlock the door;
- 2) Read unauthorized card, the buzzer gives off a beep, then a long beep when pressing the first PIN, and the door stays locked.

## 6. Installation:

### 1. Cautions during installation:

- 1) There should not be 100KHz—150 KHz frequency source within 50CM of the controller in the installation;
- 2) The installation distance between 2 unifying machines, or 1 unifying machine and other 125 KHz card reader should be  $\geq 50$ CM;
- 3) When the customer sets “Check door sensor when unlocking”, the controller checks door sensor open and close state during unlocking; when the door sensor is separated, the controller regards the door opened already. At this time, except pressing fire control door opening button, the controller will keep the door locked no matter using any other door opening mode.

### 2. Installation and line connection:

- 1) Must cut off 12VDC power supply during installation and connection. Connecting with electricity is strictly prohibited!!!

## 7. Force to restore factory defaults:

1. Remove the controller;
2. Use metal tweezer to short connect the J2, the controller gives off a beep, then 2 beeps, and the restored factory default programming PIN is 990101;

## 8. Frequently asked questions faq:

After the controller starts locks, if continues to send out 8 short sounds, The indicated the power source electric current or the voltage are insufficient.